


FRONT



PIN	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
COM1	COM	/	/	/	4E	4D	4C	4DP	3E	3D	3C	3DP	2E	2D	2C	2DP	1E	1D	1C	1B
PIN	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
COM1	1A	1F	1G	2B	2A	2F	2G	L	3B	3A	3F	3G	/	4B	4A	4F	4G	/	/	COM

OD-407